

Work Order ID 83653-2

83653

Page 1

Item ID: D350-616-011

Revision ID:

Item Name: Emergency Litter

Start Date: 23/04/2012 Start Qty: 1.00

Required Date: 07/05/2012 Req'd Qty: 1.00

Reference:

Accept

N9000040100

Setup Start *NS1*

Stop *NS2*

Cust Item ID:

Customer:

Approvals: Process Plan: MJS

Date: 12/04/23 Tooling:

Date:

Run Start *NR1*

QC:

Date: SPC (Y/N):

Date:

Stop *NR2*

Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
--------------------------------	--------------------------	----------------------	---------	--------	--------------	---------------	---------------	------------------	----------------

Draw Nbr

Revision Nbr

d350-616

E

100

0.00

100

DC

Document Control

Memo

Photocopy bluefile and create labels per PPP D350-616-011
CHG004

0.00

110

Pick Kit

0.00

110

Packaging

Memo

0.00

Packaging

120

QC4- 100% Inspect kits for completeness

0.00

120

QC

Quality Control

Memo

0.00

SP

DAS 15

2/05/10

MJS 12/07/24

④

1/x

SP
12-7-23

1/4 15

2/05/10

(+)

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

Resolution: _____ Disposition: _____ QA: N/C Closed: _____ Date: _____

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

NOTE: Date & initial all entries

Work Order ID 83653

83653

Page 2

April-23-12 10:08:50 AM

Item ID: D350-616-011

Accept

N900040100

Setup Start *NS1*

Revision ID:

Stop *NS2*

Item Name: Emergency Litter

Start Date: 23/04/2012 Start Qty: 1.00 *1*

Cust Item ID:

Required Date: 07/05/2012 Req'd Qty: 1.00 *1*

Customer:

Reference:

Approvals: Process Plan:

Date:

Tooling:

Date:

Run Start *NR1*

QC:

Date:

SPC (Y/N):

Date:

Stop *NR2*

Sequence ID/
Work Center ID

Operation
Description

Set Up/
Run Hours

Tool ID

Tool #

Plan
Code

Accept
Qty

Reject
Qty

Reject
Number

Insp.
Stamp

130

0.00

130

Packaging

Memo

0.00

Packaging

Identify and pack for shipping as per PPP D350-616-011

Location:

PPP Rev:

140

QC21- Final Inspection - Work Order Release

0.00

140

QC

Memo

0.00

Quality Control



12/8/12

MLJ 12/08/17

ME
12-08-17

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

Resolution: _____ Disposition: _____ QA: N/C Closed: _____ Date: _____

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

NOTE: Date & initial all entries

Picklist Print

April-23-12 10:08:54 AM

Page 1

Work Order ID: 83653

83653

Parent Item: D350-616-011

D350-616-011

Parent Item Name: Emergency Litter

Start Date: 23/04/2012

Required Date: 07/05/2012

Start Qty: 1.00

Required Qty: 1.00

Comments: IPP E03.04.04ReformatKJ/RF
IPP Rev:F 08-12-10 rev.E as per dwg DD verified by:ec

Component Item ID/ Item Name	Replacement Item ID	Mfg/ Purch	Bin Item	Primary Location	Last Location	Route Seq ID	Unit of Measure	Qty on Hand	Qty per Kit	Total Qty	Qty Issued	Date Issued	Status
---------------------------------	------------------------	---------------	-------------	---------------------	------------------	-----------------	--------------------	----------------	-------------	--------------	---------------	----------------	--------

D2370		Manufactured	No				Each	4.0000					
-------	--	--------------	----	--	--	--	------	--------	--	--	--	--	--

Sx4 *D2370*
Litter Assembly

Location

Loc Qty

Loc Code

ST291

2

82418

2

ST331

2

78629

2

D2493		Manufactured	No				Each	4.0000					
-------	--	--------------	----	--	--	--	------	--------	--	--	--	--	--

Sx4 *D2493*
Patient Stop Assembly

Location

Loc Qty

Loc Code

ST224

4

78617

4

D350-616-013		Manufactured	No				Each	0.0000					
--------------	--	--------------	----	--	--	--	------	--------	--	--	--	--	--

Sx4 *D350-616-013*
Deck Plate and Tie Down

14x
** 1x B85932
1x B85933
1x 85934
1x 85935

14x
** B83810 sp.

14x
** 2x 85136
1x 87163

B 88223
12/8/9

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

Resolution: _____ Disposition: _____ QA: N/C Closed: _____ Date: _____

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

NOTE: Date & initial all entries

REFERENCE ONLY

QTY - 011	Qty - 013	Qty - 015	Part Number	Description
X			D350-616-011	Full Litter Kit
1	X		D350-616-013	Deck Plate and Tie Down Kit
	1	X	D350-616-015	Deck Plate Kit
		1	D2344	DECK PLATE (AFT)
		4	D2348	WEAR PLATE (KEY WAY)
		1	D2353	STIFFENER
	1		D2360	LITTER TIE DOWN (LOCKING)
		1	D2364	DECK PLATE (FWD)
		2	D2365	WEAR PLATE (PIP PIN)
		1	D2369-1	LOCATOR PLATE
		1	D2369-3	LOCATOR PLATE
1			D2370	LITTER ASSEMBLY
1			D2493	PATIENT STOP
	1		D3179-041	LITTER TIE DOWN (NON-LOCKING)
		1	D3494-1	STUB COVER
		25	MS20426AD4-5	RIVET
		25	MS20426AD4-6	RIVET
		6	MS20426AD5-7	RIVET
		6	MS20426AD5-8	RIVET
		15	MS20601AD4W2	BLIND RIVET (or CR9162-4-2)
		30	MS20601AD4W3	BLIND RIVET (or CR9162-4-3)
		6	MS21042L3	NUT (or MS21042-3)
		6	MS24693-C273	SCREW (or MS24693-273)
		22	MS24693-C48	SCREW (or MS24693-48)
		4	MS35207-264	SCREW
		10	NAS1149D0363J	WASHER (or AN960JD10)

RELEASED
08/11/21

CANADA
DEPARTMENT OF TRANSPORT
AIRCRAFT CERTIFICATION
BRANCH
DAO # 01-O-01

APPROVED

BY: *[Signature]*
D. SHEPHERD (DE # 02)

DATE: 08.11.07
CERT. NO.: SH96-10
ISSUE NO.: 2

E	MAKE DSI 9310 STANDARD; D3179-041 REPLACES D2350	RF	08.11.07
D	ADD D3494-1 STUB COVER	MB	06.01.19
C	ADD DSI 9112/9117/9130/9236/9310	MB	06.01.10
B	ADD VIEW OF D2493 TO SHEET 9	BW	96.01.09
A	NEW ISSUE	BW	95.02.20
REV.	DESCRIPTION	BY	DATE
DESIGN	BW	DART AEROSPACE LTD	
DRAWN	RF	HAWKESBURY, ONTARIO, CANADA	
CHECKED	DS	DRAWING NO.	REV. E
MFG. APPR.	N/A	D350-616	SHEET 1 OF 12
APPROVED	DS	TITLE	SCALE
DE APPR.	<i>[Signature]</i>	AS350/355 LITTER KIT INSTALLATION	NTS
DATE	08.11.07	COPYRIGHT © 1995 BY DART AEROSPACE LTD	
THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD			

RECEIVED 1911